



# Disinfecting Cleaner

Cleaner & Disinfectant for Spray and Wipe Cleaning in Health Care and Other Facilities  
(Tuberculocidal, Bacterial & Virucidal)

Tested by Nationally Recognized Labs

Kills harmful germs in as little as **30 Seconds** when used as directed.

Effective against the following when used as directed on hard non-porous inanimate surfaces:

- Mycobacterium tuberculosis
- Salmonella enterica
- Pseudomonas aeruginosa
- Murine Norovirus MNV-1
- Clostridium Difficile (c.diff)
- Staphylococcus aureus (MRSA)
- Listeria monocytogenes
- E. coli O157:H7
- Poliovirus Chat Lsc1
- Bacteriophage MS2
- Enterovirus 68 (Enterobacter D68)



The active ingredients or mixed oxidants generated in GenEon Solution Have Been Shown to be effective against a broad range of blood borne pathogens including:

- Hepatitis A
- Hepatitis C
- Hepatitis B
- HIV
- Herpes Simplex Virus Type 1 & 2

## Specifications:

**Surfaces:** Toilet Bowl, Restrooms, Chairs, Kitchen Areas, Chopping Boards, Tables, Blood & Organic Matter, Door Knobs, Counter Tops, Stainless Steel, Sinks, Natural Stone, and other non-porous inanimate surfaces.

*\*Test in an inconspicuous area before using.*

**Contains:** 1% Hypochlorous, 99% Water

**Active Ingredients:** Classified as GRAS

Non-irritant, Non-corrosive

EPA EST. No.: 088681-KOR-001



### HMIS Hazard Ratings:



HEALTH:	1
FLAMABILITY:	0
REACTIVITY:	0

### NOTE:

Follow the instructions in product manual on how to make disinfecting solutions.  
 \*\* Solution effective for 14 days from date generated when stored as instructed.  
 \*\* Some organism were Tested using Time Kill method. Other Pathogens were tested under the AOAC Official Method 961.02: Germicidal Spray Protocol - ASTM E1053 and ASTM E1052 Standard Test Method  
 Activated with GenEon Technologies onsite generator.



# Disinfecting Cleaner



## Cleaner & Disinfectant

*Surfaces that are visibly soiled should be first cleaned with GenEon solution prior to disinfecting.*

1. Spray/Mist entire surface or area with GenEon cleaning, disinfecting, and deodorizing solution.
  - a. Confirm Solution strength (by using a FAC test strip) before spraying.
2. Allow disinfecting solution to dwell on surfaces per the instructions on the Secondary Label:
3. + Wipe Surface dry with clean cloth or towel.



### Safety Reminder

GenEon Technologies On-Site Generators, are considered a device governed by 40 CFR 156.10 and thereby is exempt from FIFRA registration by the US EPA

Follow instructions in product manual and secondary label when using all of GenEon products and Solutions

Solution produce is Not For Resale or Transport

**Caution:** Keep out of reach of children, may cause eye and skin irritation. May be harmful if swallowed. Inhalation of product may cause respiratory irritation. Avoid eye contact. Avoid prolonged or repeated contact with skin. Do not swallow. Avoid breathing product mist. Do not mix with other chemicals.

**Safety Recommendations:** Safety glasses and impervious gloves are recommended with the use of this product. Read Safety Data Sheet and Product Manual before using this product.

*Any use of this product or electrolyte outside of the manufactures specific directions is a violation of federal law.*

**24 HOUR EMERGENCY: (800)255.3924**  
**For Institutional & Industrial use only.**



(866)217-0205  
sales@geneontechnologies.com  
geneontechnologies.com

